

EVOLVEO

EasyPhone FG



www.evolveo.com

Dear customer,

Thank you for choosing an **EVOLVEO** mobile phone.



1. Torch key
2. Volume +,-
3. Right soft key
4. Left soft key
5. Navigation keys
6. SMS button
7. Camera button
8. FM button

When you power on the phone, you can set the language, time/date.

Side keys: Torch key: hold around 3 seconds to power on/off the torch

Volume +,-: adjust the volume up and down.

When the flip is closed, if you have incoming call, you can press the green button on cover to answer the call, or the red button to hang up.

1.Messages

The phone supports SMS sending. Standby interface, you can press message button to write a new message.

1.1Write Message

In the standby screen, select Menu-Message

→ write message .to enter the edit SMS interface, the following: text editing, press the left soft key "Options", you can choose to send, save, change input method etc. you can delete the contents by the right soft key. When finished, send a message, press the left soft key "send to".

1.2 Inbox

In the standby screen, select Menu → Messaging → Inbox, you can view the SIM card inbox SMS has been received, as the following options:

View: You can view a received message.

Reply: You can reply SMS to the sender.

Call sender: You can call the sender.

Forward: To forward this message to others.

Delete: Delete the current SMS.

Delete all: Delete all SMS in the inbox.

Save to Phonebook: Save this number to phonebook.

1.3 Drafts

Into the Drafts, you can view the message stored in the Drafts, and can conduct the following operations: View, Send, Edit, Delete, Delete all.

1.4 Outbox

Into the Outbox, you can view the SIM card to send and save SMS, and can do the following: View, Resend, Edit, Delete.

1.5 Sent messages

Into the Sent messages, you can view messages which were sent

1.6 SMS setting

You can find all settings for message under this menu, and you can set any of them as your request.

2. Phonebook

2.1 Add new contact

The phone offers two memory storage: the SIM card and mobile phone. You can select to save mobile numbers to SIM card or

mobile phone.

Select any contacts in the phone book list will have the following options:

View: View detailed information of this contact.

Send text message: Send a message to the contact.

Call: Call this contact.

Edit: Edit the contact.

Delete: Delete the contact.

Copy: copy in the same or a different memory and the option to save to the file management.

Add to blacklist: Add number to the black list.

Phone book settings:

Preferred storage: to SIM, Phone or All

Memory status: You can view how many phone numbers that saved.

Copy contacts: You can copy phone numbers from SIM to phone, or from phone

to SIM

Move contacts: You can move phone numbers from SIM to phone, or from phone to SIM

Delete all contacts: You can delete all phone numbers from SIM or from phone

3 Call history

3.1.1 Missed call: Enter the missed call, you can view the list of missed calls.

3.1.2 Dialed calls: To enter the dialed calls, you can view the dialed calls list.

3.1.3 Received calls: To enter the received phone, you can view the list of received phone.

3.1.4 All calls: All call records

3.1.5 Delete call logs: You can choose to delete all the call records.

4 Multimedia

4.1 Camera

Entering the camera preview screen press the “middle navigation button” to take photos.
(At standby screen, you can press Camera button to take photos as well)

4.1.1 Photos: View the photos that you saved.

4.1.2 Camera settings: Set related parameters of the camera.

4.1.3 Image settings: Set the size and quality of the photos.

4.1.4 Storage: save photos to the phone or Memory card

4.1.5 Effect settings: Set effect what you want.

4.1.6 Restore default: Restore the camera settings to default.

4.2 Image viewer

In Image viewer, you can check all photos you take via camera.

4.3 Video recorder

On the video interface, press middle button to take video recorder. Note: Because the mobile memory capacity is limited, a T-flash card has to be inserted before you can save the video.

4.4 Video player

Let you open different types of video file.

4.5 Audio player

In the music player interface, on the side key + (increase volume), the side key - (decrease volume), left navi-key (previous), right navi-key (next); through middle key play and pause music be controlled.

Music player interface, press "list" to enter the list of all the songs interface. Options to play music files in the list, update playlists and more.

4.6 Sound recorder

4.6.1 New record: Start recording.

4.6.2 List: Enter the list of recordings.

4.7 FM radio

This phone has FM radio function, can be used to listen to the radio. Press left or right navi-key to change channel. Press middle key to start or pause FM.

Press the left soft key to enter the following options:

Channel list: Edit the channel name and frequency.

Manual input: View the list of channels.

Auto search: the automatic search radio stations and save the search channel to channel list.

Settings: you can set the recording format and quality.

Note: FM reception quality and quantity
depend on the specific location.

(At Standby interface, you can press FM
button to listen to the radio.)

5 SOS setting

5.1 SOS status

You can select to switch on or switch off the
SOS function

5.2 SOS number

You can save 5 phone numbers to the SOS
emergency calling

5.3 SOS message ON/OFF

You can select to switch on or off to send
SOS message.

5.4 SOS message content

You can edit the SOS message content

5.5 Warning Tone status

You can turn on or turn off the alarm sound while pressing SOS button

6 Settings

Main menu, select "Settings", you can set up your phone menu options.

6.1 Phone settings

6.1.1 Time and date: the date and time set corresponding.

6.1.2 Language: set the phone menu display language.

6.1.3 Pref.input method: You can set the editing language, Association options, the default input method

6.1.4 Display: Set the "wallpaper" and "power on/power off display.

6.1.5 Flight mode: Set the normal mode or flight mode.

6.1.6 External display clock style: Analog or Digital

6.2 Call settings

6.2.1 Call waiting:

Set the status to be activated, deactivated, query status. Note: This function depends on the network operator. Please ask the local network operator for more detail.

6.2.2 Call divert:

The options are “Divert all voice calls”, “Divert if unreachable”, “Divert if no answer”, “Divert if busy”, “Divert all data calls”

6.2.3 Call barring:

The options are “All voice calls”, “International voice calls”, “International voice calls except to home”, “All voice calls”, “Voice calls when roaming”, “Cancel all”,

“Change barring password”. Note: This function depends on the network ops”, “Cancel all diverts”. Note: This function depends on the network operator. Please ask the local network operator for more detail.

6.2.4 Advanced setting:

Blacklist: ON/OFF. You can add or delete Blacklist numbers.

Auto redial: Able to open or close the function of auto redial. When it's on, the phone shall redial automatically after you failed dialing.

Call time reminder: The call time will display when calling if it's on.

Answer mode: Able to set answer the call by

pressing any key.

6.3 User Profiles

This phone provides a General mode, Silent mode, Meeting mode and Outdoor mode.

For each mode, you can Activate, customize or reset

6.3.1 General

6.3.1.1 Activate you can activate the general mode

6.3.1.2 Customize

- Alert type: you can select four ways of Alert: ring only, vibration only, vibration and ring, vibration then ring.
- Ring tone: Set a ringing tone.

- Ring tone volume: set the ringtone volume by pressing the left navi- key or right navi-key
- Message: Set the Message tone.
- Message volume: set the keytone volume by pressing the left navi- key or right navi-key
- Keypad: set the keypads sound mode
- Cover open : Silent or with tone
- Cover close : Silent or with tone

6.3.2 Silent mode

6.3.3 Meeting mode

6.3.4 Outdoor mode

6.4 Speed dial

You can set speed dial numbers on button 2 to 9. When one number on the button is set,

you can long press this button to call the contact.

6.5 Navigation keys

You can change menu for each navigation key: up, down, left and right navi-key.

6.6 Network settings

You can select network by set automatic or manual for the SIM you insert.

6.7 Security Settings

6.7.1 SIM Security

You can set the phone's menu security options, in order to avoid the illegal use of SIM card. PIN code to prevent the illegal use of your SIM card. If the current PIN code has been closed, select Open to open the PIN code protection, the next boot will ask for your PIN code; if the current PIN code is already open, choose to turn off the PIN code protection can be turned off, select

Security Settings -> SIM card lock -> Change password -> PIN code, you can set up a new PIN code, please follow the prompts in order to enter the old PIN, new PIN code and repeat the new PIN code.

6.7.2 Phone security

The phone lock can prevent your phone from unauthorized use.

Select the phone lock can open the phone lock password protection, the next boot will ask for your phone lock code; again to enter a password you can turn off the phone lock password protection.

Change Password: Modify the phone password.

Note: The default phone lock code is 1122, you should change your PIN.

6.8 Restore the factory settings

In this menu, enter the phone lock code to determine the mobile phone-related

parameters can be set to return to the initial value. Phone information is still retained.

Note: The default phone lock code is 1122,
you should change your PIN.

7 File manager

Used for a variety of documents and data storage management. The phone memory card can be used for capacity expansion.

8 Organizer

8.1 Calendar

Press the left key or middle key to enter the calendar display, the first line shows the year, month, day, second row shows the week, the middle section shows the specific date of a month.

In the option, you can jump to date you are looking for or go to today

8.2 Calculator

Provide users with the calculator function, can add, subtract, multiply, and divide can do the simple calculation.

8.3 Alarm

This phone provides five alarm clocks available to users, users may need to be set. Enter the alarm clock editing interface:

Use left or right navi-key to select on / off status.

Set the alarm clock.

Snooze Time: use left or right navi-key to select the default value or 1-10 minutes.

Repeat: Once, Every day or Custom

Alarm tone: You can set the alarm tone.

Alert type: Vib only, Vib and ring, Ring only

8.4 Bluetooth

Power: To open or close Bluetooth.

Visibility: Setting the visibility of Bluetooth.

When it's off, other phones can't search this phone though it has opened Bluetooth.

My device: Searching the devices which has turned on Bluetooth nearby.

Searching audio device: to search audio devices.

My name: The name shows on other phones when Bluetooth is on and the phone is searched.

The warranty does NOT apply to:

- Installing a different firmware than the one installed in the EVOLVEO phone as original from the factory.
- Electromechanical or mechanical damage to the phone caused by improper use (e.g. broken display, broken front or back cover of the phone, damaged microUSB connector, SIM card slot, microSDHC card slot, headphone jack, etc.).
- Damage to the speaker and headphones caused by metallic particles.
- Damage by natural causes like fire, water, static electricity, high temperatures.

- Defects caused by normal wear and tear.
- Damaged by unauthorized repairs
- Phone's firmware if it requires updating due to changes in mobile network parameters.
- Mobile network malfunctions □ Battery if it does not retain its original capacity after 6 months and more (warranty for battery capacity is for 6 months).
- Intentional damage.

Warranty and post-warranty service

Repairs and servicing may only be carried out in an authorized service centres for EVOLVEO products (see www.evolveo.com),

otherwise you may damage your mobile phone and lose the warranty.



Disposal: The symbol of crossed out container on the product, in the literature or on the wrapping means that in the European Union all the electric and electronic products, batteries and accumulators must be placed into the separate salvage after finishing their lifetime. Do not throw these products into the unsorted municipal waste



DECLARATION OF CONFORMITY

Hereby, the company Abacus Electric, s.r.o. declares that the EVOLVEO EasyPhone FG is in compliance with the requirements of the standards and regulations, relevant for the given type of device.

Find the complete text of Declaration of Conformity at <ftp://ftp.evolveo.com/ce>

Dovozce / Dovozca / Importer / Importör

Abacus Electric, s.r.o.

Planá 2, 370 01, Czech Republic

Výrobce / Výrobca / Manufacturer / Gyártó

Naxya Limited

No. 5, 17/F Bonham Trade Centre, 50
Bonham Strand, Sheung Wan, Hong Kong
Made in China

Copyright © Abacus Electric, s.r.o.
www.evolveo.com
www.facebook.com/EvolveoCZ

All rights reserved.

Design and specification may be changed
without prior notice.